

<b>Telefoane compatibilee (nu necesita repornirea aparatului)</b>	<b>Telefoane incompatibile (necesita repornirea manuala a aparatului)</b>	<b>Telefoane partial compatibile (repornire automata a aparatului)</b>
Siemens A70	Nokia 6060	Sagem My400V
Siemens A75	Nokia 1100	Sagem MyC2-3
Nokia 3100	Nokia 1110	Nokia 3110 clasic
Nokia 6680	Siemens A50	
Nokia N70	Nokia 3410	
Samsung ZV10	Siemens A57	
Motorola C350	Nokia 2600	
Samsung X120	Sony Ericsson T100	
Sharp GX29	Nokia 6500	
Samsung D600	Alcatel OT153	
Nokia 7270	Nokia 6280	
Sony Ericsson V630i	LG U 8130	
Nokia N90	Sagem MyC5-2	
Motorola V535	Nokia 9300	
Sony Ericsson Z300	Nokia 6020	
Sharp GX17	Nokia 6021	
Nokia 3250	Nokia 1600	
Motorola C650	LG KP230	
Nokia 6230i	Nokia 2310	
Nokia 6600	Nokia 6085	
Nokia 3220		
Nokia 6630		
Nokia 6170		
Nokia 8800		
Nokia 6234		
Motorola V3X		
Nokia E61		
Blackberry 7290		
HTC TyTn II		
Motorola RAZR V8		
Motorola W230		
Motorola W375		
Nokia 1110i		
Nokia 6070		
Nokia 7900 prism		
Nokia E50		
Samsung L770V		
Samsung SGH J700		
Sony Ericsson P910i		
Sony Ericsson X123		
Vodafone 810		